



SC 3 Upright EasyFix

Carefree deep cleaning using steam: The SC 3 Upright EasyFix is extremely easy to operate and can be used on hard floors. It also removes 99.99% of common household bacteria.



1 Preset steam flow control in three steps for cleaning different surfaces

- Selection options of floor covering symbols for wood, tiles and carpet to set the ideal steam flow.

2 Non-stop steam and integrated descaling cartridge

- The removable tank is easy to fill at any time - for continuous steam without interrupting your work.
- Thanks to the intelligent descaling cartridge, limescale is removed automatically.

3 Short heat-up time

- With a heat-up time of only 30 seconds, the device is ready to use in no time.

4 The LED strap on the device signals heat-up and whether it is ready to use

- Extremely easy application thanks to the device's continuous feedback to the user regarding its operating status.
- Red pulsating light indicates the device is heating up and a constant green light indicates that the device is ready to use.



SC 3 Upright EasyFix

- Three-stage steam flow control with floor type symbols to ensure the perfect steam flow
- Ready to use in 30 seconds; no additional descaling thanks to descaling technology
- Continuously fillable tank for uninterrupted use

Technical data

Order no.	1.513-300.0	
EAN code	4054278290911	
Area performance per tank filling	m ²	ca. 60
Heating output	W	1600
Cable length	m	5
Heat-up time	min	0.5
Tank capacity	l	0.5
Current type	Ph / V / Hz	1 / 220-240 / 50-60
Weight without accessories	kg	3.1
Weight incl. packaging	kg	4.38
Dimensions (L × W × H)	mm	314 × 207 × 1185


Equipment

Child safety lock/safety valve	- / ■
Steam flow control	three-stage adjustment depending on the type of flooring
Integrated filling funnel	■
Microfibre floor cloth	piece(s) 1
Carpet glider	■
Descaling cartridge	■
Integrated on/off switch	■
Removable fresh water tank	■

■ Included in the scope of supply. * When thoroughly cleaning with the Kärcher steam cleaner, 99.99 % of all common household bacteria will be killed on common household hard surfaces.

SC 3 UPRIGHT EASYFIX 1.513-300.0

KÄRCHER



		Order no.	Quantity				Price	Description	
Nozzles									
Carpet glider	1	2.863-269.0	1 piece(s)					Also ensures fresh carpet fibres: The carpet glider for easy attachment to the floor nozzle EasyFix. Ideal for steam cleaning carpets.	■
Miscellaneous									
Descaling cartridge	2	2.863-018.0						Quick and efficient descaling of the Kärcher SC 3 EasyFix steam cleaner. All you need to do is insert the cartridge, and you're done.	■
Cloth kit									
Microfibre cloth set for floor nozzle EasyFix	3	2.863-259.0	2 piece(s)					Cloth can be changed without having to come into contact with dirt: the high-quality Easyfix microfibre floor cloth. Thanks to the hook-and-loop system, they are easy and quick to attach to and remove from the EasyFix steam cleaner floor nozzle.	□
EasyFix disposable cloth set	4	2.863-299.0	15 piece(s)					Set of 15 disposable cloths for the EasyFix floor nozzle for fast and hygienic cleaning of hard surfaces. The yellow hook-and-loop strips enable the cloth to be attached easily.	□
Abrasive cloth set abrasiv for floor nozzle EasyFix	5	2.863-309.0	2 piece(s)					The EasyFix abrasive floor cleaning cloths remove even stubborn stains from scratch-resistant stone floors. The hook-and-loop system allows easy attachment and removal without contact with dirt.	□

■ Included in the scope of supply. □ Available accessories.